
ADEPTUS

ASSEMBLY INSTRUCTIONS

Cottage Four Drawer Chest #78105 - White Finish



CUSTOMER SERVICE AND REPLACEMENT PARTS:

FOR FASTER SERVICE ON PARTS, PLEASE GO TO OUR WEBSITE AT WWW.ADEPTUS.COM; OR CALL TOLL FREE 1.888.ADEPTUS (1.888.233.7887) FOR ASSEMBLY QUESTIONS. MON-FRI 10 A.M. TO 4 P.M. E.S.T., CLOSED HOLIDAYS.

IF YOU CALL, PLEASE HAVE ON HAND:

- PRODUCT NAME AND STOCK NUMBER
- WHEN AND WHERE THE UNIT WAS PURCHASED
- P.O. NUMBER FROM THE BOTTOM OF THIS PAGE

IF WE ARE BUSY HELPING OTHER CUSTOMERS, PLEASE LEAVE YOU NAME AND NUMBER TO RECEIVE A RETURN CALL. YOUR RETAILER MAY ALSO PROVIDE SERVICE OR PARTS.

HELPFUL OVERALL:

- SAVE THESE INSTRUCTION SHEETS AND THE BOX UNTIL YOU ARE SATISFIED WITH THE ASSEMBLY.
- DO NOT GLUE THE PARTS OF THE UNIT TOGETHER UNLESS YOU HAVE TESTED THE ASSEMBLY FIRST.
- PERFORM THE ASSEMBLY ON A CLEAN HARD SURFACE USING THE FLATTENED CARTON OR A TOWEL TO PROTECT THE SURFACE AND THE FINISH OF THE UNIT. DO NOT ASSEMBLE ON CARPET.

VISIT WWW.ADEPTUS.COM TO REGISTER YOUR PRODUCT AND SEE THE COMPLETE ADEPTUS LINE. REGISTRATION IS REQUIRED FOR PARTS REQUESTS.

THANK YOU FOR YOUR PURCHASE AND WELCOME TO ADEPTUS!



Many People, One Thought

PROVIDING QUALITY SOLID WOOD FURNITURE AT AN AFFORDABLE PRICE HAS BEEN A GROUP EFFORT. FROM CONCEPT TO PRODUCT DESIGN, MANUFACTURING AND RETAILING, EACH AREA FOCUSES ON THE DETAILS THAT WILL ASSURE YOU A LOW PRICE. BUT NEVER AT THE EXPENSE OF FUNCTION, STYLING, OR GOOD SENSE.

A "READY - TO - ASSEMBLE" ITEM REDUCES TRANSPORTATION AND WAREHOUSING COSTS WHICH HELP YOUR RETAILER KEEP THEIR PRICES REASONABLE. NOW, YOU ARE JOINING "TEAM ADEPTUS" WITH THE FINAL STEP, ASSEMBLY.

· YOUASSEMBLE, YOUSAVE ·

WELCOME TO ADEPTUS!



This is a **SOLID WOOD** product:

We inspect all wood and follow quality assurance guidelines that pass third-party inspections.

Note: Real wood has knots, small cracks, and what may look like blemishes. These characteristics are expected when producing furniture from natural material.

We take extra care with our drawer parts:

- 1. We use real wood drawer sides and drawer backs.
- 2. Drawer sides and backs are not finished to protect fabrics from any residual paint odor.
- Drawer parts are finely sanded to prevent snags.




Perform assembly on a clean, hard surface using the flattened box or a towel to protect the surface & the unit's finish. DO NOT assemble on carpet.

Carpet creates too much bounce making assembly difficult and could lead to damage of the parts.





DO NOT FORCE OR **OVER-TIGHTEN THE** SCREWS. DOING SO CAN DAMAGE THE PARTS.




Safety and Care Advice

- · Check that you have all the components and tools listed on pages 3 & 4.
- · Remove all fittings from the plastic bags and separate them into their groups.
- · Keep children and animals away from the work area, small parts could choke if swallowed.
- · Make sure you have enough space to layout the parts before starting.
- · Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Opened box can be used to protect your floor or counter during assembly.
- · Assembly is easier for drawer parts on a counter.
- · Parts of the assembly will be easier with 2 people.
- · We do not recommend the use of power drill/drivers for inserting screws, as overtightening could damage the unit.
- · Only use hand screwdrivers.
- · Dispose of all packaging carefully and responsibly. Please recycle the box. Go green
- · Never sit, stand or allow children to climb on the assembled unit.





Parts List Legend							
#	Description	Qty					
01	Тор	1					
02	Left Facing Side Panel	1					
03	Right Facing Side Panel	1					
04	Bottom Crossbars	2					
05	Back Panels	2					
06	Drawer Back	4					
07	Drawer Crossbars	4					
08	Drawer Bottoms	4					
09	Small Drawer Front	1					
10	Large Drawer Fronts	3					
11	Left Drawer Sides	4					
12	Right Drawer Sides	4					




A=52 8 x 30 mm Dowel	8=56 4 x 30 mm Screw	C=02 16 x 5 mm Washer	D=33 3.5 x 14 mm	E=04 (300E) Left Drawer Runner	F=04 (300D) Right Drawer Runner	G=08 + 2 xtra
H=16 6 x 10	I=02 7 x 50	J=01	K=22 + 6 xtra	L=01	M=02	N=01
mm Screw	Anti- tip Screw	Wrench	Back Panel Nail	150 mm Anti-tip safety Strap	Anti-tip Screw Cover	Anti-tip Wall Anchor
A			0-04			


IMPORTANT INFORMATION:


- Do not use power tools for assembly.
- Assembly is easier with 2 people.
- Perform assembly steps in order as listed.
- Some parts do not have pre-drilled "pilot" holes for screws. This is intentional to optimize the grip of the screw on the wooden part and prevent possible stripping.
- Individual wooden & MDF parts are not sticker-ed with corresponding part numbers. This is intentional to prevent possible damage to the finish and allow you additional cost savings. The above illustration should be used together with the Parts Lists legend to identify the parts for assembly.


These tools are not supplied by the manufacturer:



PREPARE PARTS BY INSERTING DOWELS









PREPARE THE PARTS FOR ASSEMBLY BY INSERTING DOWELS (PART A) AS FOLLOWS:

- Insert 2 dowels (part A) into the top of each side panel (parts 02 & 03).
- Insert 2 dowels (part A) into both ends of each bottom crossbar (part 04).
- Insert 2 dowels (part A) into both ends of the drawer crossbars (part 07).
- Insert 2 dowels each into the front end of each of the drawer sides (parts 10 & 11).

ATTACH THE FEET TO THE SIDE PANELS



- Attach the feet (part O) to the bottom of each side panel as shown.
- Do NOT try to force or over-tighten the feet. This could cause damage.



3

ATTACH ANTI-TIP SAFETY STRAP



L=01

150 mm

Anti-tip safety

Strap






A

WARNING

SERIOUS OR FATAL CRUSHING INJURIES CAN OCCUR FROM FURNITURE TIP-OVER. TO AVOID TIP-OVER:


- PLACE HEAVIEST ITEMS IN THE LOWEST DRAWERS.
- UNLESS SPECIFICALLY DESIGNED TO ACCOMODATE, DO NOT SET TV'S OR OTHER HEAVY OBJECTS ON TOP OF THIS PRODUCT.
- NEVER ALLOW CHILDREN TO CLIMB OR HANG ON DOORS, DRAWERS OR SHELVES.
- NEVER OPEN MORE THAN ONE DRAWER AT A TIME.
- KEEP REMOTE CONTROLS, TOYS AND OTHER ITEMS THAT MAY ATTRACT CHILDREN OFF OF THIS PRODUCT.

USE OF TIP-OVER RESTRAINTS MAY ONLY REDUCE, BUT NOT ELIMINATE, THE RISK OF TIP-OVER.




Attach the Anti-tip Safety Strap (part L) to the Top (part 01):

- Position and hold one end of the strap (part L) to the center of the bottom, back of the top (part 01) just in front of the
 cut out.
- Place a washer (part C) on top of the strap (part L).
- Secure the strap (part L) by screwing the Part D screw through the washer (part C) and the strap (part L) into the top (part 01).
- Part D screw should be tight, but do not force or over-tighten as this could cause the wood to split.




Screws (part H) should just be tight. Do not try to force or over-tighten as this may cause damage to the panel or runners.


left side panel (part 02) using 8 of the part H screws.




Screws (part H) should just be tight. Do not try to force or over-tighten as this may cause damage to the panel or runners.





- each crossbar (parts 04 & 07) to the right side panel (part 03) by first aligning the dowels (part A) you inserted in step 1 on each crossbar (parts 04 & 07) with the pre-drilled dowel holes in the right side panel (part 03).
- Once aligned, push all crossbars (parts 04 & 07) into the the right side panel (part 03) until flush.
- Secure each crossbar (parts 04 & 07) using 6 of the part B screws.
- The part B screws should be just tight. Do not force or over-tighten as this could cause damage to the panel or crossbars.





- Attach all crossbars (parts 04 & 07) to the left side panel (part 02) by first aligning the dowels (part A) you inserted in step 1 on each crossbar (parts 04 & 07) with the pre-drilled dowel holes in the left side panel (part 02).
- Once aligned, push all crossbars (parts 04 & 07) into the the left side panel (part 02) until flush.
- Secure each crossbar (parts 04 & 07) using 6 of the part B screws.
- The part B screws should be just tight. Do not force or over-tighten as this could cause damage to the panel or crossbars.











ANCHOR THE UNIT TO A WALL




WARNING

SERIOUS OR FATAL CRUSHING INJURIES CAN OCCUR FROM FURNITURE TIP-OVER. TO AVOID TIP-OVER:

- PLACE HEAVIEST ITEMS IN THE LOWEST DRAWERS.
- UNLESS SPECIFICALLY DESIGNED TO ACCOMODATE, DO NOT SET TV'S OR OTHER HEAVY OBJECTS ON TOP OF THIS PRODUCT.
- NEVER ALLOW CHILDREN TO CLIMB OR HANG ON DOORS, DRAWERS OR SHELVES.
- NEVER OPEN MORE THAN ONE DRAWER AT A
- KEEP REMOTE CONTROLS, TOYS AND OTHER ITEMS THAT MAY ATTRACT CHILDREN OFF OF THIS PRODUCT.


USE OF TIP-OVER RESTRAINTS MAY ONLY REDUCE, BUT NOT ELIMINATE, THE RISK OF TIP-OVER.








N=01



Important note: If plastic wall plugs



If you have any doubt regarding the correct wall plug to use, please seek professional advice.





- Secure the unit to a wall to reduce the risk of accidental tip-over by inserting the wall anchor (part N) into your wall approximately 990 mm (or 39 inches) above the floor level.
- Hold the washer (part C) on the front side top of the anti-tip safety strap (part L).
- Feed the screw (part B) through the washer (part C) and strap (part L) into the wall anchor (part N).
- Tighten the screw (part B) until secure.

- Tilt the back of each drawer upward to get it past the wheels on the drawer runners.
- Once clear of the wheels, you can level the drawers and slide them in.
- Then repeat the dowel step for each side of each drawer.




If you will store more than 10 lbs in any one drawer, you MUST insert a dowel (part A) into each side of the drawer as shown. This will prevent the drawer from extending too far and causing possible tip-over.





80=A 8 x 30 Dowel



Screw




After completed assembly, it is necessary to adjust the drawer alignment to get the drawers perfectly square.

To adjust the drawer front position:

- Loosen the screw (part H) you used to install the drawer runner (either parts E or F) in steps 6 or 7, to the side panel (parts 02 or 03), depending on the side (left or right), as shown.
- With the screw (part H) loosened, you can make the necessary slight adjustments (up or down) to the drawer runner to achieve the proper drawer alignment.

Once the drawer alignment is square, secure the position of the drawer runners (parts E & F) to the side panels (parts 02 & 03) by retightening the part H screw and adding the part D screw as shown.

Complete these steps for both the left and the right side of each drawer.



Completed Assembly!

Care and use instructions:

Use for general home storage of clothing items and accessories.

Clean with a damp cloth and wipe dry.

Do not use harsh chemicals or abrasive sponges or cloths that could damage the finish.